



in vitro
Diagnostic

BBL™ CultureSwab™ Collection & Transport System



H157FM - Rev. (1102)
L003320



Peel
Détacher
Abziehen
Aprire
Destacar e abrir
Despegue



Discard cap.
Retirer le bouchon.
Entfernen des
Togliere il cappuccio.
Remover a tampa.
Quite el tapón.



Collect specimen.
Ecouvillonner.
Probe entnehmen.
Prelevare il campione.
Colher a amostra.
Tome la muestra.



Insert swab.
Replacer l'écouvillon.
Tupfer einführen.
Inserire il tampone.
Inserir o swab.
Introduzca el aplicador.

STERILE A (C) 0000

Made by Cope in
Beckton, Dickinson Company
Sparks, MD, USA

BECKTON Dickinson

Beckton, Dickinson USA
10000 Le Parc Drive, Irvine

CA 92618-1697

L = LOT

DI = DI

Hospital No.	
Age	Sex
Specimen	

220109
LA STUART
029947 L 7FC709